



Important Safety Instructions

When using or storing these products, the following safety precautions should be adhered to:

1. Use of power supply not sold by Cronopower is not recommended and could result in a risk of fire or injury to persons.
2. Store products in a cool and dry place.
3. Do not store products in hot or humid environments.
4. Operating temperature should be between 32°F to 104°F (0°C to 40°C).
5. Do not disassemble product. Repairable products should only be sent to Cronopower for service.
6. While charging motors, the MotorTap may feel warm, this is normal operating condition and should be be cause for concern.
7. Do not dispose of product in heat or fire.
8. Do not clean product with water or harmful chemicals and detergents.
9. Misuse, dropping, or excessive force may cause product temperature.